



suggestions for low and high current magnetic field monitoring

Achim Franz, BNL

after asking around I could not find any usable probes, so I suggest we use the old PHENIX Hall probes we used for the original field mapping in 1999 and another test in 2003.

Plus a single 3D probe, LakeView, with separate GPIB readout, but it does have a very short cable, 6', we ordered the wrong replacement length.






mapping fixture 1999

test in 2003, trying to
get this running again


plate with probes

Keithley 2000 DMM
and 7002 switch



3. Hall Probe with Amplifier Board HT1D-AB

~ 400 Probes build
and tested by Russian
colleagues, booklet
with constants
available.





1. Control current "-"
2. Control current "+"
3. GND Black
4. -15V Blue
5. +15V Red
6. GND
7. Output voltage "+"

Note: The positive voltage appears at the lead 7, when the magnetic field vector is directed as shown and control current enters in to the lead 2.

Accuracy of calibration:


Magnetic sensitivity.	$\pm 5.0E-4$
Offset voltage.	$\pm 0.7 \text{ mV}$
Output voltage temperature coefficient.	$\pm 5.0E-3 \text{ } \%/^{\circ}\text{C}$
Offset voltage temperature coefficient.	$\pm 0.02 \text{ mV}/^{\circ}\text{C}$
"Planar" Hall coefficient.	$\pm 10 \text{ mV/T}^2$



General Specifications Hall Probe with Amplifier Board, Model HT1D-AB.



1. Hall Probe HT1D

All Hall probes are mounted in the housings with accuracy $\pm 0,25$ mm in any direction relatively the point "C" and adjusted up to 0.06 degree (1millirad) in two independent directions relatively the bottom base surface of the housings.



Note: all dimensions are in mm.



2. Amplifier Board AB



Note: all dimensions are in mm.


Resistors C2-29B		Chip Capacitors	
Element	Nominal	Element	Nominal
R1, R2	1k	C1	10nF
R3, R4	100k	C2, C4	100nF
R5	10k	C3, C5	10 μ F(16VDC)

readout cables,
2 may work,
18 probes each



Keithley 2000 DMM
and 7002 switch

this is a set of monitoring probes for the MuonMagnetSouth
create something similar on a Al unistrut base
placed on the cryostat floor



testing readout with an old Mac and PyVisa



PyVISA is a Python package that enables you to control all kinds of measurement devices independently of the interface (e.g. GPIB, RS232, USB, Ethernet). As an example, reading self-identification from a Keithley Multimeter with GPIB number 12 is as easy as three lines of Python code:

```
>>> import visa
>>> rm = visa.ResourceManager()
>>> rm.list_resources()
('ASRL1::INSTR', 'ASRL2::INSTR', 'GPIB0::12::INSTR')
>>> inst = rm.open_resource('GPIB0::12::INSTR')
>>> print(inst.query("*IDN?"))
```

(That's the whole program; really!) It works on Windows, Linux and Mac; with arbitrary adapters (e.g. National Instruments, Agilent, Tektronix, Stanford Research Systems).

<https://pyvisa.readthedocs.org/en/stable/>